

COMMERCIAL WARRANTY

This product is warranted by BRANICK INDUSTRIES, INC. to the original user-owner against defective materials or workmanship for a period of one year from the date of shipment. During the warranty period, at the discretion of Branick management, if the product is found to be defective, it will be repaired or replaced without charge. For service, contact Branick (800-437-4394) to obtain an RMA. Any product shipped to Branick must have an RMA and proof of original shipment date. The repaired or replacement product will be returned with transportation charges prepaid by Branick.

This warranty does not cover defects in the product caused by ordinary wear and tear, abuse, misuse, overloading, accident (including shipping damage), improper maintenance, alteration, or any other cause not the result of defective materials or workmanship.

REPAIR OR REPLACEMENT IS THE EXCLUSIVE REMEDY FOR DEFECTIVE PRODUCT UNDER THIS WARRANTY. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANT ABILITY OR ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OF THIS PRODUCT. BRANICK INDUSTRIES, INC. SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES.

BRANICK INDUSTRIES, INC. reserves the right to make changes in the design or construction of our products without obligation to incorporate such changes in products already sold and without notice.

Service parts and regular repair service are available from authorized distributors of Branick products, or from:

BRANICK INDUSTRIES, INC.
4245 Main Ave.
Fargo, North Dakota 58103
Toll Free: 800-437-4394



MODEL 135
PORTABLE
AIRSTATION

Operation &
Repair Parts
Information



Power Requirements & Charging Instructions

- The system is powered by a 12 volt rechargeable battery.
- Charge the airstation by connecting the power cord into the charger socket on the back of the unit and plugging the other end into a 110/120 volt outlet.

NOTE: Under no circumstances should the battery be left in the flat state designated by a blank display or diagnostic code "LO".

- Charging a completely flat battery could take up to 7 hours to obtain a full charge.
- The length of battery charge is dependent upon many factors including use, how often charged, etc. Once fully charged, the system should provide up to 8 hours of continuous use.

Service Parts

ITEM	QTY	PART NO.	DESCRIPTION
1	1	01-0265	HANDLE WITH THREADED INSERT
2	1	02-0023	BLOCKHEAD INFLATOR (w/HARNES)
3	4	10-0032	RUBBER BUMPER
4	4	028-155	10-24 X 5/8" RD HD SCREW
5	1	40-0064	12V CHARGER
6	1	40-0076	12V BATTERY
7	1	41-0042	ON/OFF ROCKER SWITCH
8	1	42-0023	6' POWER CORD
9	1	43-0048	POWER ENTRY MODULE
10	2	50-0077	3/8-16 X 3/4" SBHC SCREW
11	6	50-0125	1/4-20 X 5/8" SOC BTN HC SCREW
12	2	50-0140	#10-24 X 1/2" FLAT HD C'SUNK MACH SCREW
13	10	055-127	#10-24 HEX LOCK NUT
14	2	055-160	1/4-20 HEX LOCK NUT
15	1	59-0085	VELCRO BATTERY STRAP
16	2	60-0191	3/8" TB X 1/4" NPT M CONN FITTING
17	2	60-0192	1/4" NPT X 3/4-16 STR BHD FITTING
18	2	60-0231	3/8" X 1/4" NPT 90° SWL ELBOW FITTING
19	1	60-0320	CLIP-ON CHUCK (OPEN)
20	1	62-0044	1/4" NPT X 10' RECOIL HOSE
21	1	72-0251	FLANGED CHARGER TRAY
22	1	72-0437	INFLATOR BRACKET
23	1	72-0491	PORTABLE TOP PANEL
24	1	72-0492	PORTABLE BOTTOM PANEL
25	1	72-0517	BATTERY TRAY
26	1	60-0194	1/4" NPT BRASS ELBOW
27	4	108-110	1/4" SAE FLAT WASHER
28	1	932-001	IN-LINE FILTER
29	1	D20-006	3/8" O.D. NYLON TUBE (BLACK)

Service Parts Diagram

